

# LANDS'END

## Women's 2-button Washable Wool Blazer

### Item Dimensions

Find your size in the horizontal bar. The vertical numbers below each size are the actual garment measurements in inches.

#### REGULAR

	4	6	8	10
Body chest	34	35	36	37
Garment chest	36 3/4	37 3/4	38 3/4	39 3/4
Garment length – center back	21 1/2	21 3/4	22	22 1/4
Garment length – across shoulders	15 1/4	15 1/2	15 3/4	16
Garment sleeve length – center back	32	32 3/8	32 3/4	33 1/8

#### REGULAR

	12	14	16	18
Body chest	38 1/2	40	41 1/2	43 1/2
Garment chest	41 3/4	43 3/4	45 3/4	47 3/4
Garment length – center back	22 1/2	22 3/4	23	23 1/4
Garment length – across shoulders	16 3/8	16 3/4	17 1/8	17 5/8
Garment sleeve length – center back	33 1/2	33 7/8	34 1/4	34 5/8

**PETITE**

	00P	0P	2P	4P	6P
<b>Body chest</b>	31	32	33	34	35
<b>Garment chest</b>	33 3/4	34 3/4	35 3/4	36 3/4	37 3/4
<b>Garment length – center back</b>	19 3/4	20	20 1/4	20 1/2	20 3/4
<b>Garment length – across shoulders</b>	14	14 1/4	14 1/2	14 3/4	15
<b>Garment sleeve length – center back</b>	29 1/8	29 1/2	29 7/8	30 1/4	30 5/8

**PETITE**

	8P	10P	12P	14P	16P
<b>Body chest</b>	36	37	38 1/2	40	41 1/2
<b>Garment chest</b>	38 3/4	39 3/4	41 3/4	43 3/4	45 3/4
<b>Garment length – center back</b>	21	21 1/4	21 1/2	21 3/4	22
<b>Garment length – across shoulders</b>	15 1/4	15 1/2	15 7/8	16 1/4	16 5/8
<b>Garment sleeve length – center back</b>	31	31 3/8	31 3/4	32 1/8	32 1/2

**PLUS**

	<b>18W</b>	<b>20W</b>	<b>22W</b>	<b>24W</b>	<b>26W</b>
<b>Body chest</b>	45	16-Feb	49	51	53
<b>Garment chest</b>	48 1/2	50 1/2	52 1/2	54 1/2	56 1/2
<b>Garment length – center back</b>	24	24 1/4	24 1/2	24 3/4	25
<b>Garment length – across shoulders</b>	18	18 1/4	18 1/2	18 3/4	19
<b>Garment sleeve length – center back</b>	33 5/8	33 7/8	34 1/8	34 3/8	34 1/2