

LANDS' END

Women's Down System Commuter Coat Item Dimensions

Find your size in the horizontal bar. The vertical numbers below each size are the actual garment measurements in inches.

REGULAR

	XS(2-4)	S(6-8)	M(10-12)	L(14-16)	XL(18)
Body chest	33-34	35-36	37-38 1/2	40-42	44
Garment chest – shell	40	42	44 1/2	48	50
Garment chest – liner	40	42	44 1/2	48	50
Garment length – center back – shell	35 1/2	36	36 1/2	37 1/4	37 3/4
Garment length – center back – liner	33 1/2	34	34 1/2	35 1/4	35 3/4
Garment sleeve length – center back – shell	32 3/4	33 1/2	34 1/4	35	35 1/2
Garment sleeve length – center back – liner	32 1/4	33	33 3/4	34 1/2	34 3/4

PETITE

	XS(2-4)	S(6-8)	M(10-12)	L(14-16)	XL(18)
Body chest	33-34	35-36	37-38 1/2	40-42	44
Garment chest – shell	40	42	44 1/2	48	50
Garment chest – liner	40	42	44 1/2	48	50
Garment length – center back – shell	32 3/4	33 1/2	34 1/4	34 3/4	35 1/2
Garment length – center back – liner	30 3/4	31 1/2	32 1/4	32 3/4	33 1/2
Garment sleeve length – center back – liner	31	31 3/4	32 1/2	33 1/4	33 1/2
Garment sleeve length – center back – shell	30 1/2	31 1/4	32	32 3/4	33 1/4

PLUS

	1X(16W-18W)	2X(20W-22W)	3X(24W-26W)
Body chest	43-45	47-49	51-53
Garment chest – shell	54	58	62
Garment chest – liner	52 1/2	56 1/2	60 1/2
Garment length – center back – shell	38	38 5/8	39 1/4
Garment length – center back – liner	36	36 5/8	37 1/4
Garment sleeve length – center back – shell	35	35 1/2	35 7/8
Garment sleeve length – center back – liner	34	34 1/2	34 7/8