

LANDS'END

Women's Thermaskin™ Heat Cami

Item Dimensions

Find your size in the horizontal bar. The vertical numbers below each size are the actual garment measurements in inches.

REGULAR

	XS(2-4)	S(6-8)	M(10-12)	L(14-16)	XL(18)
Body chest	33-34	35-36	37-38 1/2	40-42	44
Garment chest	30	32	34 1/2	37 1/2	39 1/2
Garment length – center front	15 3/4	16 1/4	16 3/4	17 1/4	17 3/4
Garment sweep	31	33	35 1/2	38 1/2	40 1/2

PLUS

	0X(14W)	1X(16W-18W)	2X(20W-22W)	3X(24W-26W)
Body chest	42 1/2	44-46	48-50	52-54
Garment chest	36 1/2	40	44	48
Garment length – center front	18 3/4	19 1/4	19 3/4	20 1/4
Garment sweep	41 1/2	45	49	53