

Women's Fit 1 5-pocket White Ankle Pants

Item Dimensions

Find your size in the horizontal bar. The vertical numbers below each size are the actual garment measurements in inches.

REGULAR

	2	4	6	8	10
Body waist	26 1/2-27 1/2	27 1/2-28 1/2	28 1/2-29 1/2	29 1/2-30 1/2	30 1/2-31 1/2
Garment waist	29 1/2	30 1/2	31 1/2	32 1/2	33 1/2
Garment seat	35 1/2	36 1/2	37 1/2	38 1/2	39 1/2
Garment front rise	8	8 1/4	8 1/2	8 3/4	9
Garment back rise	13 5/8	14	14 3/8	14 3/4	15 1/8
Garment bottom opening	11 7/8	12 1/4	12 5/8	13	13 1/8
Garment inseam	28	28	28	28	28

REGULAR

	12	14	16	18
Body waist	32-33	33 1/2-34 1/2	35-36 1/2	37-38 1/2
Garment waist	35	36 1/2	38 1/2	40 1/2
Garment seat	41	42 1/2	44	46
Garment front rise	9 3/8	9 3/4	10 1/8	10 1/2
Garment back rise	15 5/8	16 1/8	16 5/8	17 1/8
Garment bottom opening	13 3/8	13 5/8	13 7/8	14 1/8
Garment inseam	28	28	28	28

PETITE

	2P	4P	6P	8P	10P
Body waist	26 1/2-27 1/2	27 1/2-28 1/2	28 1/2-29 1/2	29 1/2-30 1/2	30 1/2-31 1/2
Garment waist	29 1/2	30 1/2	31 1/2	32 1/2	33 1/2
Garment seat	35 1/2	36 1/2	37 1/2	38 1/2	39 1/2
Garment front rise	7 1/2	7 3/4	8	8 1/4	8 1/2
Garment back rise	13 1/8	13 1/2	13 7/8	14 1/4	14 5/8
Garment bottom opening	11 5/8	12	12 3/8	12 3/4	12 7/8
Garment inseam	25 1/2	25 1/2	25 1/2	25 1/2	25 1/2

PETITE

	12P	14P	16P	18P
Body waist	32-33	33 1/2-34 1/2	35-36 1/2	37-38 1/2
Garment waist	35	36 1/2	38 1/2	40 1/2
Garment seat	41	42 1/2	44	46
Garment front rise	8 7/8	9 1/4	8 5/8	10
Garment back rise	15 1/8	15 5/8	16 1/8	16 5/8
Garment bottom opening	13 1/8	13 3/8	13 5/8	13 7/8
Garment inseam	25 1/2	25 1/2	25 1/2	25 1/2

TALL

	6	8	10	12	14	16	18
Body waist	28 1/2-29 1/2	29 1/2-30 1/2	30 1/2-31 1/2	32-33	33 1/2-34 1/2	35-36 1/2	37-38 1/2
Garment waist	31 1/2	32 1/2	33 1/2	35	36 1/2	38 1/2	40 1/2
Garment seat	37 1/2	38 1/2	39 1/2	41	42 1/2	44	46
Garment front rise	9	9 1/4	9 1/2	9 7/8	10 1/4	10 5/8	11
Garment back rise	14 7/8	15 1/4	15 5/8	16 1/8	16 5/8	17 1/8	17 5/8
Garment bottom opening	12 5/8	13	13 1/8	13 3/8	13 5/8	13 7/8	14 1/8
Garment inseam	30	30	30	30	30	30	30

PLUS

	14W	16W	18W	20W	22W	24W	26W
Body waist	36 1/2-37 1/2	38-39	40-41	42-43	44-45	46-47	48-49
Garment waist	36 1/2	38	40	42	44	46	48
Garment seat	44	45 1/2	47 1/2	49 1/2	51 1/2	53 1/2	55 1/2
Garment front rise	11 1/4	11 5/8	12	12 3/8	12 3/4	13 1/8	13 1/2
Garment back rise	16 7/8	17 1/2	18	18 5/8	19 1/8	19 5/8	20 1/4
Garment bottom opening	15 1/2	15 3/4	16	16 1/4	16 1/2	16 3/4	17
Garment inseam	28	28	28	28	28	28	28