



Men's Primadown Commuter Coat

Item Dimensions

Find your size in the horizontal bar. The vertical numbers below each size are the actual garment measurements in inches.

REGULAR

	S(34-36)	M(38-40)	L(42-44)	XL(46-48)	XXL(50-52)
Garment chest – 1" below armhole	45	48	52	56	60
Garment length – center back	36 1/2	37	37 3/4	38 1/2	39 1/4
Garment sleeve length – center back	35 1/2	36 1/2	37 1/2	38 1/2	39

TALL

	M(38-40)	L(42-44)	XL(46-48)	XXL(50-52)
Garment chest – 1" below armhole	48	52	56	60
Garment length – center back	38 1/2	39 1/4	40	40 3/4
Garment sleeve length – center back	38	39	40	40 1/2