

Girls' Yoga Capri Pants

Item Dimensions

Find your size in the horizontal bar. The vertical numbers below each size are the actual garment measurements in inches.

TODDLER

	2T	3T	4T
Body height in.	33-35	36-38	39-41
Body weight lbs.	27-29	30-33	34-38
Body waist	20	20 1/2	21
Garment waist – relaxed	18	18 1/2	19
Garment waist – extended	27	27 1/2	28
Garment seat	21 1/2	22 1/2	23 1/2
Garment inseam	8 7/8	9 3/4	10 1/2

LITTLE GIRL

	4	5	6
Body height in.	40-42	43-45	46-48
Body weight lbs.	34-38	39-43	42-48
Body waist	22	22 1/2	23
Garment waist – relaxed	19 1/2	20	20 1/2
Garment waist – extended	27 1/2	28 1/2	29 1/2
Garment seat	23	24	25
Garment inseam	13	13 1/2	14

BIG GIRL

	7	8	10	12	14	16
Body height in.	49-51	52-54	55-57	58-60	61-62	62-63
Body weight lbs.	52-58	61-68	71-87	85-95	99-110	109-120
Body waist	23 1/2	24 1/4	25	26	28	30
Garment waist – relaxed	21	21 3/4	22 1/2	23 1/2	25	27
Garment waist – extended	28	29	31	32 1/2	34	36
Garment seat	27 1/2	28 1/2	30 1/2	32	34	36
Garment inseam	17 7/8	18 1/2	19 1/4	20	20 5/8	21 1/4

GIRL PLUS

	7P	8P	10P	12P	14P	16P
Body height in.	49-51	52-54	55-57	58-60	61-62	62-63
Body weight lbs.	63-71	72-80	81-90	91-108	109-120	121-131
Body waist	27 1/2	28	28 1/2	30 1/2	32	34
Garment waist – relaxed	24 1/2	25 1/4	26	27	28 1/2	32 1/2
Garment waist – extended	31 1/2	32 1/2	34 1/2	36	37 1/2	39 1/2
Garment seat	30 1/2	31 1/2	33 1/2	35	37	39
Garment inseam	17 7/8	18 1/2	19 1/4	20	20 5/8	21 1/4