

LANDS' END

Women's Core Down Vest

Item Dimensions

Find your size in the horizontal bar. The vertical numbers below each size are the actual garment measurements in inches.

REGULAR

	XS(2-4)	S(6-8)	M(10-12)	L(14-16)	XL(18)
Body chest	33-34	35-36	37-38 1/2	40-42	44
Garment chest – 1" below armhole	39 1/2	41 1/2	44	47 1/2	49 1/2
Garment length – center back	23 7/8	24 1/2	25 1/8	25 3/4	26 3/8
Garment sweep	41	43	45 1/2	48 1/2	50 1/2

PETITE

	XS(2P-4P)	S(6P-8P)	M(10P-12P)	L(14P-16P)	XL(18P)
Body chest	33-34	35-36	37-38 1/2	40-42	44
Garment chest – 1" below armhole	39 1/2	41 1/2	44	47 1/2	49 1/2
Garment length – center back	22 7/8	23 1/2	24 1/8	24 3/4	25 3/8
Garment sweep	41	43	45 1/2	48 1/2	50 1/2

TALL

	S(6T-8T)	M(10T-12T)	L(14T-16T)	XL(18T)
Body chest	35-36	37-38 1/2	40-42	44
Garment chest – 1” below armhole	41 1/2	44	47 1/2	49 1/2
Garment length – center back	26	26 5/8	27 1/4	27 7/8
Garment sweep	43	45 1/2	48 1/2	50 1/2

PLUS

	0X(14W)	1X(16W-18W)	2X(20W-22W)	3X(24W-26W)
Body chest	42 1/2	43-45	47-49	51-53
Garment chest – 1” below armhole	48 1/2	52	56	60
Garment length – center back	25 7/8	26 1/2	27 1/8	27 3/4
Garment sweep	50 1/2	54	58	62