LANDS' END

Women's Active Crop Yoga Pants

Item Dimensions

Find your size in the horizontal bar. The vertical numbers below each size are the actual garment measurements in inches.

REGULAR

	XS(2-4)	S(6-8)	M(10-12)	L(14-16)	XL(18)
Body waist	26 1/2-28 1/2	28 1/2-30 1/2	30 1/2-33	33 1/2-36 1/2	37-38 1/2
Garment waist – relaxed, extends 9”	26	28	30 1/2	34	36
Garment seat	35 1/2	37 1/2	40	43	45
Garment front rise – excluding gusset	9 1/8	9 5/8	10 1/4	11	11 3/8
Garment back rise – including gusset	14	14 3/4	15 5/8	16 5/8	17 1/8
Garment bottom opening	14 1/2	15 1/4	16	16 3/4	17 1/4
Garment inseam	24	24	24	24	24

PETITE

	XS(2P-4P)	S(6P-8P)	M(10P-12P)	L(14P-16P)	XL(18P)
Body waist	26 1/2-28 1/2	28 1/2-30 1/2	30 1/2-33	33 1/2-36 1/2	37-38 1/2
Garment waist – relaxed, extends 9”	26	28	30 1/2	34	36
Garment seat	35 1/2	37 1/2	40	43	45
Garment front rise – excluding gusset	8 5/8	9 1/8	9 3/4	10 1/2	10 7/8
Garment back rise – including gusset	13 1/2	14 1/4	15 1/8	16 1/8	16 5/8
Garment bottom opening	14 1/4	15	15 3/4	16 1/2	17
Garment inseam	21 1/2	21 1/2	21 1/2	21 1/2	21 1/2

TALL

	XS(2-4)	S(6T-8T)	M(10T-12T)	L(14T-16T)	XL(18T-20T)
Body waist	26 1/2-28 1/2	28 1/2-30 1/2	30 1/2-33	33 1/2-36 1/2	37-38 1/2
Garment waist – relaxed, extends 9”	26	28	30 1/2	34	36
Garment seat	35 1/2	37 1/2	40	43	45
Garment front rise – excluding gusset	9 5/8	10 1/8	10 3/4	11 1/2	11 7/8
Garment back rise – including gusset	14 1/2	15 1/4	16 1/8	17 1/8	17 5/8
Garment bottom opening	14 1/2	15 1/4	16	16 3/4	17 1/4
Garment inseam	25 1/2	25 1/2	25 1/2	25 1/2	25 1/2

PLUS

	1X(16W-18W)	2X(20W-22W)	3X(24W-26W)
Body waist	38-41	42-45	46-49
Garment waist – relaxed, extends 9”	36	40	44
Garment seat	50	54	58
Garment front rise – excluding gusset	11 1/4	12	12 3/4
Garment back rise – including gusset	18 1/8	19 1/4	20 3/8
Garment bottom opening	19	19 1/2	20
Garment inseam	23	23	23