

LANDS' END

Plain Front Blend Chino Shorts

Item Dimensions

Find your size in the horizontal bar. The vertical numbers below each size are the actual garment measurements in inches.

KIDS

	2	3	4	5	6	7	8
Body height in.	33-35	36-39	40-42	43-45	46-47	48-49	50-53
Body weight lbs.	27-29	30-33	34-38	39-42	43-48	49-54	55-67
Garment waist	19 1/8	19 1/2	19 7/8	20 1/2	21 1/2	22 1/2	25 1/2
Garment seat	25 3/4	26 1/4	26 3/4	27 7/8	29	30 1/4	31 1/2
Garment inseam	4 1/4	4 3/4	5 3/4	6 1/4	6 3/4	7 1/4	7 3/4

KIDS

	10	12	14	16	18	20
Body height in.	54-56	57-59	60-62	63-65	66-67	68-69
Body weight lbs.	68-80	81-94	95-108	109-120	121-132	133-145
Garment waist	26 1/2	27 1/2	29	30 1/2	32	33 1/2
Garment seat	32 3/4	34 1/4	35 3/4	37 1/4	38 7/8	40 1/4
Garment inseam	8 1/8	8 1/2	8 7/8	9 1/4	9 1/2	9 3/4

KIDS SLIM

	2S	3S	4S	5S	6S	7S	8S
Body height in.	33-35	36-39	40-42	43-45	46-47	48-49	50-53
Body weight lbs.	27-29	30-33	28-32	33-36	37-42	43-47	48-58
Garment waist	17 1/8	17 1/2	17 7/8	18 1/2	19 1/2	20 1/2	23 1/2
Garment seat	24 1/2	25	25 1/2	26 5/8	27 3/4	29	30 1/4
Garment inseam	4 1/4	4 3/4	5 3/4	6 1/4	6 3/4	7 1/4	7 3/4

KIDS SLIM

	10S	12S	14S	16S	18S	20S
Body height in.	54-56	57-59	60-62	63-65	66-67	68-69
Body weight lbs.	59-71	72-83	84-96	97-109	110-122	123-135
Garment waist	24 1/2	25 1/2	27	28 1/2	30	31 1/2
Garment seat	31 1/2	33	34 1/2	36	37 1/2	39
Garment inseam	8 1/8	8 1/2	8 7/8	9 1/4	9 1/2	9 3/4

KIDS HUSKY

	8H	10H	12H	14G	16H	18H	20H
Body height in.	50-53	53-56	57-59	60-62	63-65	66-67	68-69
Body weight lbs.	62-75	76-90	91-105	106-119	120-134	135-148	149-161
Body waist	27 1/2	28 1/2	29 1/2	31	32 1/2	34	35 1/2
Garment waist	28 1/2	29 1/2	30 1/2	32	33 1/2	35	36 1/2
Garment seat	34 1/2	35 3/4	37 1/4	38 3/4	40 1/4	41 7/8	43 1/4
Garment inseam	7 3/4	8 1/8	8 1/2	8 7/8	9 1/4	9 1/2	9 3/4

MEN'S REGULAR

	27	28	29	30	31	32	33	34
Garment waist	28 3/4	29 3/4	30 3/4	31 3/4	32 3/4	33 3/4	34 3/4	35 3/4
Garment seat	37	38	39	40	41	42	43	44
Garment front rise	10 3/4	10 7/8	11 1/8	11 1/4	11 3/8	11 5/8	11 3/4	11 7/8
Garment back rise	15 1/4	15 1/2	15 3/4	16	16 1/4	16 1/2	16 3/4	17
Garment bottom opening	20 3/4	21 1/4	21 3/4	22 1/4	22 3/4	23 1/4	23 3/4	24 1/4
Garment inseam	11	11	11	11	11	11	11	11

MEN'S REGULAR

	35	36	36	37	38
Garment waist	36 3/4	37 3/4	37 3/4	38 3/4	39 3/4
Garment seat	45	46	46	47	48
Garment front rise	12	12 1/8	12 1/8	12 3/8	12 1/2
Garment back rise	17 1/4	17 1/2	17 1/2	17 3/4	18
Garment bottom opening	24 5/8	25	25	25 3/8	25 3/4
Garment inseam	11	11	11	11	11

MEN'S REGULAR

	40	42	44
Garment waist	41 3/4	43 3/4	45 3/4
Garment seat	49 1/2	51	52 1/2
Garment front rise	12 3/4	12 7/8	13
Garment back rise	18 1/2	19	19 1/2
Garment bottom opening	26 1/2	27 1/4	28
Garment inseam	11	11	11

MEN'S LONG

	34	36	38	40	42	44
Garment waist	35 3/4	37 3/4	39 3/4	41 3/4	43 3/4	45 3/4
Garment seat	41	43	45	46 3/4	48 1/2	50 1/4
Garment front rise	12 3/8	12 5/8	13	13 1/4	13 3/8	13 1/2
Garment back rise	17 1/2	18	18 1/2	19	19 1/2	20
Garment bottom opening	24 1/4	25	25 3/4	26 1/2	27 1/4	28
Garment inseam	11 1/2	11 1/2	11 1/2	11 1/2	11 1/2	11 1/2